



ROYAL COPENHAGEN

Harmony - Lysestager  
Harmony - Candlesticks  
Harmony - Leuchter



Harmony - Lysestager  
Harmony - Candlesticks  
Harmony - Leuchter

Design  
Michael Bang



Opal/Opal/Opal

4 342 109

Lysestage, lille  
Candlestick, small  
Leuchter, klein

145 mm/5 1/2 inch

4 342 110

Lysestage, mellem  
Candlestick, medium  
Leuchter, mittel

203 mm/8 inch

4 342 111

Lysestage, stor  
Candlestick, large  
Leuchter, gross

270 mm/10 5/8 inch

Forhandler/Dealer/Händler

Brug lysmanchet og fjern lyset før det er brændt helt ned.  
Always use board base and remove the candle stump  
before the flame reaches the glass.

Immer Lichtmanschette verwenden und die Kerze  
entfernen, bevor Sie ganz heruntergebrannt ist.

9 420 702

PRINTED IN DENMARK BY FROM & CO.



**ROYAL COPENHAGEN**

PURVEYOR TO HER MAJESTY THE QUEEN OF DENMARK